

ALUMINUM SURROUND GRILLE INSTALLATION INSTRUCTIONS

STEP 1: Set the grille in the window opening with the preapplied bumpers against the glass.

STEP 2: Shim between the grille frame and window frame to center the grille in the window opening.

STEP 3: Drill a 5/32" hole through the window frame at each predrilled hole in the grille frame.

STEP 4: Install the supplied #10-24 x 3/4" screws into the holes and remove the shims.

STEP 5: Adjust the screws as needed.

